

Steering Remote Supported Vehicles



MAKER	MODEL	YEAR	INTERFACE	HARNESS	CONNECTOR	Type	*Connector	**Con. Loc.
Alfa Romeo	147	01>	KCE-870B(R15+)	KWE-897E	Mini ISO yellow	resistor	3	A
	156	00>	KCE-870B(R15+)	KWE-897E	Mini ISO yellow	resistor	3	A
Audi	A6	01>09/04	KCE-858B	Not needed	Mini ISO green	bus	3	A
	3 Series	95>	KCE-864B(R2+)	Not needed	17p. BMW Block	bus	4	A
BMW	5 Series	95>10/02	KCE-864B(R2+)	Not needed	17p. BMW Block	bus	4	A
	5 Series (Inc. X5)	10/02>	KCE-861B	Not needed	40p. MOST connector	bus	5	A
	Mini (with 17 pin connector)	02>	KCE-864B(R2+)	Not needed	17p. BMW Block	bus	4	A
	Mini (with 40 pin connector)	02>	KCE-861B	Not needed	40p. MOST connector	bus	5	A
Chrysler	Grand Cherokee	99>01	KCE-866B	Not needed	6 way grey AMP	bus	14	C
Citroen	C3, C5, C8	01>	KCE-862B	Not needed	8 way ISO	bus	1	A
	Xsara I	96>99	KCE-870B(R3+)	KWE-876E	8 way ISO	resistor	1	A
	Xsara II	99>00	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	Xsara III	00>01	KCE-870B(R8+)	KWE-894E	5 way black CINCH	resistor	15	C
	Xsara Picasso	00>01	KCE-870B(R8+)	KWE-894E	5 way black CINCH	resistor	15	C
	Xantia I	93>98	KCE-870B(R3+)	KWE-874E	10 way ISO	resistor	2	A
	Xantia II	98>99	KCE-870B(R3+)	KWE-875E	10 way ISO	resistor	2	A
	Xantia III	99>	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	XM	89>95	KCE-870B(R3+)	KWE-880E	7 way Philips	resistor	6	A
	Evasion/Synergie I	96>99	KCE-870B(R3+)	KWE-878E	7 way Philips	resistor	6	A
	Evasion/Synergie II	96>99	KCE-870B(R3+)	KWE-881E	Mini ISO green	resistor	3	A
	Evasion/Synergie III	00>	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
Fiat	Punto	95>99	KCE-870B(R3+)	KWE-885E	8 way ISO	resistor	1	A
	Marea	96>99	KCE-870B(R3+)	KWE-886E	Mini ISO green	resistor	3	A
	Ulysse I	95>96	KCE-870B(R3+)	KWE-878E	7 way Philips	resistor	6	A
	Ulysse II	96>99	KCE-870B(R3+)	KWE-881E	Mini ISO green	resistor	3	A
	Ulysse III	00>	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	Focus (not C-Max)	99>10/04	KCE-870B(R4+)	KWE-888E	17 way Ford	resistor	12	A
Ford	Mondeo	01>	KCE-870B(R4+)	KWE-888E	17 way Ford	resistor	12	A
	Mondeo	96>00	KCE-840B(R4)	KWE-850E	7 way Ford	switch	13	A
	Scorpio	96>99	KCE-840B(R4)	KWE-850E	7 way Ford	switch	13	A
	Galaxy	>02	KCE-869B	Not needed	6 way	bus	10	C
	Galaxy	02>03	KCE-870B(R4+)	KWE-888E	17 way Ford	resistor	12	A
	S2000	99>00	KCE-865B	Not needed	20 way	voltage	20	A
Jeep	Cherokee	02>	KCE-866B	Not needed	6 way grey AMP	bus	14	C
Lancia	Zeta I	95>96	KCE-870B(R3+)	KWE-878E	7 way Philips	resistor	6	A
	Zeta II	96>99	KCE-870B(R3+)	KWE-881E	Mini ISO green	resistor	3	A
	Zeta III	00>02	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	Freelander	01>	KCE-870B(R12+)	KWE-872E	8 way ISO	resistor	1	A
Land Rover	Freelander	02>	KCE-870B(R8+)	KWE-895E	17p. BMW Block	resistor	4	A
	Discovery I	96>98	KCE-870B(R3+)	KWE-887E	8 way ISO	resistor	1	A
	Discovery II	99>00	KCE-870B(R4+)	KWE-889E	8 way ISO	resistor	1	A
	Discovery II	00>	KCE-870B(R8+)	KWE-895E	17p. BMW Block	resistor	4	A
Mercedes	C-Class, C-Sportcoupe	00>09/02	KCE-863B	Not needed	10 way ISO	bus	2	A
	C-Class, C-Sportcoupe	09/02>03/04	KCE-860B	Not needed	10 way ISO	bus	2	A
	E-Class, CLK	99>09-02	KCE-868B	Not needed	no picture	bus	2	D
	Astra	99>03	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
Opel	Omega	94>	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
	Corsa	00>	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
	Agila	00>	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
	Sintra	97>99	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
	Vectra	95>03	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
	Zafira	99>	KCE-870B(R3+)	KWE-871E	8 way ISO	resistor	1	A
Peugeot	206 4 function	99>	KCE-840B(R4)	KWE-851E	6 way green CINCH	switch	16	C
	206 6 function	99>	KCE-870B(R8+)	KWE-891E	6 way black CINCH	resistor	17	C
	206 4 function	01>	KCE-870B(R8+)	KWE-896E	3 way small CINCH	resistor	18	C
	206	02>	KCE-862B	Not needed	8 way ISO	bus	1	A
	306 I	93>99	KCE-840B(R4)	KWE-848E	10 way ISO	switch	2	A
	306 II	99>00	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	307	02>	KCE-862B	Not needed	8 way ISO	bus	1	A
	406 D8	96>99	KCE-870B(R3+)	KWE-877E	7 way Philips	resistor	6	A
	406 D9 with sep. display	99>03	KCE-870B(R8+)	KWE-893E	4 way brown PSA	resistor	19	C
	806 I	95>96	KCE-870B(R3+)	KWE-878E	7 way Philips	resistor	6	A
	806 II	96>99	KCE-870B(R3+)	KWE-881E	Mini ISO green	resistor	3	A
	806 III	00>02	KCE-870B(R8+)	KWE-890E	Mini ISO yellow	resistor	3	A
	806 IV	01>02	KCE-870B(R8+)	KWE-893E	4 way brown PSA	resistor	19	C
	807	02>	KCE-862B	Not needed	8 way ISO	bus	1	A
	306 405 605	93>99	KCE-840B(R4)	KWE-847E	6 way round DIN	switch	11	A
	Range Rover	97>98	KCE-870B(R3+)	KWE-873E	8 way ISO	resistor	1	A
Renault	19	88>96	KCE-840B(R4)	KWE-842E	6 way round DIN	switch	11	A
	21	84>94	KCE-840B(R4)	KWE-842E	6 way round DIN	switch	11	A
	25	84>92	KCE-840B(R4)	KWE-842E	6 way round DIN	switch	11	A
	Espace I	88>90	KCE-840B(R4)	KWE-842E	6 way round DIN	switch	11	A
	Twingo Model 2000	00>	KCE-840B(R4)	KWE-852E	Mini-ISO	switch	3	A
	Twingo Model 2000	98>	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	Clio I	90>98	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	Clio II	98>00	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	Safrane	93>00	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	Espace II & III	91>03	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	Scenic / Laguna	96>00	KCE-840B(R4)	KWE-843E	10 way ISO	switch	2	A
	All with separate Display	96>00	KCE-840B(R4)	KWE-844E	15 way red Molex	switch	7	B
	All with separate Display	00>02	KCE-840B(R4)	KWE-845E	15 way red Molex	switch	8	B
Rover	200, 400, 600, 800	97>99	KCE-870B(R3+)	KWE-872E	8 way ISO	resistor	1	A
	25, 45	99>	KCE-870B(R3+)	KWE-872E	8 way ISO	resistor	1	A
	75	00>	KCE-870B(R8+)	KWE-895E	17p. BMW Block	resistor	4	A
	9-3, 9-5	99>	KCE-867B	Not needed	3 way	voltage	9	C
Saab	Alhambra	>02	KCE-869B	Not needed	6 way	bus	10	C
Seat	Alhambra	02>	KCE-859B	Not needed	Mini ISO	bus	3	A
	Sharan	>02	KCE-869B	Not needed	6 way	bus	10	C
VW	Sharan	02>	in prep.	in prep.	in prep.	bus		
	Golf IV, Passat, Bora	00>10/03	KCE-859B	Not needed	Mini ISO green	bus	3	A

Terminology:

MAKE	Car Brand
MODEL	European Car name (partly not compatible to US or other Markets)
YEAR	Approximate Model Year Range
INTERFACE	Required Interface
HARNESS	Required Harness (If "not needed", the Interface has already a Car connector)
CONNECTOR	Connector Shape and type
Type	Type of interface
Connector	Picture number of interface (ref. To folder Illustrations)
Con. Loc.	Location of Connector (ref. To folder Connector locations)

* Connector: Picture number of interface (ref. to page 26)

** Con. Loc.: Location of Connector (ref. to page 26)

As vehicle manufacturers often change connectors and colour codes, it is recommended to first check the connector type in the vehicle. It is possible that other models of the same manufacturer can be controlled by Alpine interfaces if they have an equivalent connector.