


# **ALPINE** **SERVICE MANUAL**

---

## MULTIMEDIA MANAGER™



- \* The model described in this manual is developed from Model PXA-H700.  
For information that is not mentioned in this service manual, refer to the Service Manual • PXA-H700 (Part No. 68E35821S01).  
< Please refer to PROCESSOR UNIT of PXA-H700. >



2 / 04-A  
68E36304S01



# PXA-H701

## <Cautions for Safe Repair Work>



The following cautions will prevent accidents in the workplace and will ensure safe products.

\*The symbols indicate caution is needed to prevent injuries and damage to property.



The symbols and their meanings follow.

 <b>Warning</b>	If you ignore this symbol and handle the product incorrectly or unsafely, serious injury or death may result.
 <b>Caution</b>	If you ignore this symbol and handle the product incorrectly or unsafely, injury or only material damage may result.









\*The following symbols indicate two levels of cautions.

 When you see this symbol, you have to be very careful.	
 When you see this symbol, you have to follow the instructions there.	

### **Warning**


 <b>Do not look squarely into the laser light coming from the pickup.</b> You may lose your sight.	 <b>Fuse Caution</b> Always use a designated fuse. Use of an incorrect fuse may result in a fire.
--	--

### **Caution**

 <b>Do not allow wiring to be caught in the screw/chassis.</b> If wiring is caught in the screw/chassis, it may cause a short circuit, resulting in a fire.	 <b>Battery Caution</b> Use the designated battery. Confirm the correct polarity and seat of the battery. An incorrect battery or an improperly connected or seated battery may result in a fire.
 <b>High Temperature Caution</b> Touching the heat sink may cause severe burns.	 <b>Designated Parts Caution</b> Look up the part list and ensure that only designated parts are used to prevent problems or accidents.
 <b>Reverse Power Supply Connections or Misconnections Caution</b> Reverse power supply connections or misconnections may cause ignition problems and smoke may result.	 <b>Wiring Caution</b> Ensure that the wiring is correct when rewiring to prevent problems with ignition/breakdown.
 <b>Soldering Caution</b> Hot solder from solder splash may cause severe burns.	 <b>Wear Gloves</b> Wear gloves to prevent electrical shocks or injury from the end face of the metal.

## Contents

<b>Packing Assembly Parts List</b>	4
<b>Packing Method View</b>	4
<b>&lt;PROCESSOR Unit&gt;</b>	5 , 6

Specifications	 Refer to the Service Manual - PXA-H700 (Part No. 68E35821S01).
System Connection	
Block Diagram	

NOTE : Due to continuing product improvement, specifications and designs are subject to change without notice.


Packing Assembly Parts List

Symbol No.	Part No.	Description
#1 101	68-00493Z08	OWNER'S MANUAL
\$1 101	68-00493Z09	OWNER'S MANUAL
102	01T55561W37	ASSY ,DIN(AINET/5500)

Symbol No.	Part No.	Description
103	03E36299S01	SCR,M4X14 TPG1.BLK(CR FREE)
104	75E26094S01	PAD,MAGIC TAPE
105	01E34618S01	ASSY ,KIT WIRE 6P5557-06

NOTE : #1 : For North American Model Only, \$1 : For General Foreign Model Only, Others : Common.


Packing Method View



## &lt;PROCESSOR Unit&gt;

**Electrical Parts List (Only Difference)**

6

Parts Layout on P.W.Boards and Wiring Diagram	 Refer to the Service Manual - PXA-H700 (Part No. 68E35821S01).
Schematic Diagram	
Terminal Voltage of IC/ TR	
Description of IC Terminal	
Exploded View (Cabinet)(PROCESSOR Unit)	

NOTE : Due to continuing product improvement, specifications and designs are subject to change without notice.

# Electrical Parts List (Only Difference)

NOTE : For the parts not mentioned, refer to the Service Manual for PXA-H700 (Part No. 68E35821S01).

Model	PXA-H700		PXA-H701	
Symbol No.	Part No.	Description	Part No.	Description
MAIN P.W.Board				
Transistor			Transistor	
Q203	48E22877S01	TR,2SC3693 M,L,K	48E36297S01	TR,2SC4551
DSP P.W.Board				
IC			IC	
IC506	51T65804Y01	IC,UPD70F3030BYGC	51T65804Y06	IC,UPD70F3030BYGC